



E-01 SHROUD ASSY




Ref. No	Part Number	Description	Reqd. No.
1	19610-F6A-0004	Fan cover COMP.	1
2	1962A-AFA-0000	Shroud A ASSY.	1
3	1963A-F6A-0001	Shroud B ASSY.	1
4	93904-35380	Tapping screw 5*16	6
5	96001-06028-08	SH. flange bolt 6*28	4
6	18241-H4C-0000	EXH. pipe protector	1

E-02 CYLINDER HEAD




Ref.No	Part Number	Description	Reqd. No.
1	1230A-ARA-0012	Cylinder head cover ASSY.	1
2	1865A-ARA-0003	A.I.C.V. ASSY.	1
3	12200-ARA-0005	Cylinder head COMP.	1
4	12209-H6B-9000	Valve stem seal	2
5	12237-F6A-3000	Valve guide	2
6	12251-H6B-0002	Cylinder head gasket	1
7	12391-ARA-0100	Head cover packing	1
8	12392-ARA-0002	Cylinder head stay	1
9	1443A-F6A-0002	Valve rocker arm ASSY.	2
10	14451-H6B-0000	IN. rocker arm shaft	2
11	14711-F6A-0000	IN. valve	1
12	14721-F6A-0000	EXH. valve	1
13	14751-ARA-0000	Valve spring	2
14	14771-F6C-A000	Retainer valve spring	2
15	14781-A01-A000	Valve cotter	4
16	16201-M92-0002	CARB. insulator gasket	1
17	16211-M92-0003	CARB. insulator	1
18	90033-M92-0000	Stud bolt 6*55	2
19	90034-HMA-0001	Special stud bolt 8*40	2
20	91301-028-0000	O ring 27*2	1

E-02-1 CYLINDER HEAD




Ref.No	Part Number	Description	Reqd. No.
21	91305-M9Q-0001	O-ring 9*1.6	2
22	94050-08080	Nut flange 8MM	4
23	96001-06025-08	SH. flange bolt 6*25	4
24	96001-06095-08	Flange SH bolt 6*95	2
25	98056-57718-NGK	PLUG. spark(NGK CR7HSA)	1

E-03 CAM SHAFT&CYL. HEAD L. SIDE COVER




Ref. No	Part Number	Description	Reqd. No.
1	14100-ARA-0002	Cam shaft COMP.	1
2	14105-F6A-0000	Cam sprocket	1
3	14401-F6A-0000	Cam chain	1
4	14457-F6A-0000	Cam shaft setting plate	1
5	14510-F6A-0000	Cam chain tensioner	1
6	14610-F6A-0100	Cam chain guide	1
7	96001-06016-08	SH. flange bolt 6*16	1
8	90083-B12-0000	Knock bolt 6MM	2

E-04 R CRANK CASE&OIL PUMP ASSY




Ref. No	Part Number	Description	Reqd. No.
1	11100-ARA-0004	R. crank case COMP.	1
2	11102-M9Q-3000	ENG. hanger rubber bush	1
3	15100-F6C-0001	Oil pump ASSY.	1
4	15133-F6C-0001	Oil pump driven gear	1
5	28101-GY6-9000	Starter reduction gear	1
6	28102-GY6-9000	Start. red. gear shaft	1
7	28110-M9Q-0002	Start. clutch gear COMP	1
8	28120-M9Q-0007	Starting clutch outer COMP.	1
9	28124-H6T-0000	Starter clutch roller spring	3
10	28125-M92-0002	Starting clutch flange COMP.	1
11	28126-M9Q-0000	Starting roller spring cap	3
12	90002-M9Q-0001	Socket bolt 6*10	3
13	90201-GY6-9000	Lock nut 22MM	1
14	90403-M92-0000	Thrust washer 22.2*31*1.5	1
15	90602-N01-0000	C-clip 8mm	2
16	91104-M9Q-0000-M2	Needle bearing 28*32*17	1
17	91105-M9Q-0002	Roller 10*10	3
18	91201-GY6-9031	Oil seal 19.8*30*5R	1
19	96001-06045-08	Flange bolt 6*45	1
20	96001-06055-08	Flange bolt 6*55	1

E-05 CYLINDER




Ref. No	Part Number	Description	Reqd. No.
1	12101-ARB-0000	Cylinder	1
2	12191-F6C-0000	Cylinder gasket	1
3	14520-GY6-9011	Tensioner lifter ASSY.	1
4	14523-GY6-9000	Tensioner lifter gasket	1
5	90001-M9Q-0000	SH. flange bolt 6*22	2
6	90031-M92-0001	Cylinder stud bolt A	2
7	90032-A6A-0000	Cylinder stud bolt B	2
8	90703-M8Q-0003	Dowel pin 10*14	4

E-06 R. CRANK CASE COVER




Ref. No	Part Number	Description	Reqd. No.
1	11331-ARB-0002	R. crank case cover	1
2	11394-F6C-0000	R. cover gasket	1
3	12361-M9Q-0001	Tappet adjusting hole cap	1
4	15421-H66-0000	Oil filter screen	1
5	15426-M9Q-0000	Oil filter screen SPG.	1
6	1565A-ARA-0000	Oil level gauge ASSY	1
7	19613-GY6-9000	Start. motor cord clammer	1
8	32961-ARA-0000	ACG cord clammer	1
9	91302-M9T-0002	O-ring 30.8MM	1
10	94301-08140	Dowel pin 8*14	2
11	96001-06100-08	SH flange bolt 6*100	2
12	96001-06095-08	Flange sh bolt 6*95	6
13	96001-06030-08	SH. flange bolt 6*30	2

E-07 AC GEN. ASSY




Ref. No	Part Number	Description	Reqd. No.
1	19510-F6A-0102	Cooling fan COMP.	1
2	31110-F6C-0000	Flywheel COMP	1
3	31120-Z7A-0001	Stator COMP.	1
4	90440-166-0000	Plain washer 12MM	1
5	94050-12000	Flange nut 12MM	1
6	92101-05012-0A	HEX bolt 5*12mm	2
7	96001-06018-08	Flange bolt 6*18	4
8	96001-06028-08	SH. flange bolt 6*28	2

E-08 L. CRANK CASE COVER




Ref. No	Part Number	Description	Reqd. No.
1	11341-ARA-0004	L. crank case cover	1
2	11342-ARA-0004	L. side cover plate	1
3	11360-M92-3000	Kick starter driven shaft	1
4	11381-ARA-0000	Throttle cable clamp	1
5	11382-ARB-0001	Brake cable clamer	1
6	11395-ARA-0001	L. cover gasket	1
7	28230-H6T-0000	Kick driven gear COMP.	1
8	28233-M92-0001	Kick starter friction SPG	1
9	28250-ARA-0000	Kick starter spindle	1
10	28254-KG8-910A	Kick spindle bush 14*18*16	1
11	28281-ARA-0000	Kick return spring	1
12	96001-06030-00	SH. flange bolt 6*30	8
13	90451-M9Q-0000	Kick spindle washer	1
14	90452-M9Q-0000	Thrust washer 12MM	1
15	94511-14000	EX. cir-clip 14mm	1

E-09 MOVABLE DRIVE FACE ASS'Y




Ref. No	Part Number	Description	Reqd. No.
1	2211A-ARA-0000	Movable drive face ASSY.	1
2	22102-M92-0004	Drive face COMP.	1
3	22105-M92-0000	Drive face boss	1
4	22110-H5B-0001	Movable drive face COMP.	1
5	22121-HKE-0000	Weight roller COMP.	6
6	22131-M92-0002	Ramp plate	1
7	22132-ARA-0000	Slide piece	3
8	23100-ARA-0100	Drive belt	1
9	90440-166-0000	Plain washer 12MM	1
10	91202-A6A-0000	Oil seal 25*40*7	1
11	94050-12000	Flange nut 12MM	1

E-10 DRIVEN PULLEY ASS'Y




Ref. No	Part Number	Description	Reqd. No.
1	2301A-F6C-0000	Driven pulley set	1
2	22101-M9Q-0003=	Clutch outer	1
3	22350-HKE-0001	Drive plate COMP.	1
4	22530-F6C-0000	Clutch weight	1

E-11 MISSION CASE&DRIVE SHAFT




Ref. No	Part Number	Description	Reqd. No.
1	21200-ARB-0006	Mission case COMP.	1
2	21395-ABA-0000	Mission cover gasket	1
3	23411-ARA-0001	Drive shaft	1
4	23420-HHB-0100	Counter shaft COMP.	1
5	23431-ARB-0001	Final shaft	1
6	23432-HHB-0100	Final gear 43T	1
7	90703-M8Q-0003	Dowel pin 10*14	2
8	91003-M8Q-0000	Radial ball BRG. CSB301	1
9	91104-KN7-6700-M2	Radial ball BRG. CSB204	1
10	91201-HHA-3001	Oil seal 32*47*7	1
11	91202-KJ9-0030	Oil seal 20*32*6	1
12	94510-22000	EX. cir-clip 22MM	1
13	96100-62033-10	Radial ball BRG. 6203	1
14	96100-63013-00	Radial ball BRG 6301	2
15	96150-62043-10	Ball radial bearing 6204	1

E-12 L. CRANK CASE




Ref. No	Part Number	Description	Reqd. No.
1	11102-M9Q-3000	ENG. hanger rubber bush	1
2	11192-F6C-0000	R. crank case gasket	1
3	11200-ARA-0006	L. crank case COMP.	1
4	11203-M9Q-3000	RR. CUSH. UN. rubber bush	1
5	14531-M9Q-0000	Cam chain tensioner pivot	1
6	31200-ARA-0002	Start motor ASSY.	1
7	90103-KN8-000A	Special bolt 8MM	1
8	90474-333-0000	Washer 8MM	1
9	90703-M8Q-0003	Dowel pin 10*14	2
10	91304-M9Q-0000	O-ring 15.2*1.5	1
11	92800-12000	Drain plug bolt 12MM	1
12	94109-12000	Plug drain washer 12mm	1
13	94301-08140	Dowel pin 8*14	2
14	96001-06016-08	SH. flange bolt 6*16	2

E-13 CRANK SHAFT




Ref. No	Part Number	Description	Reqd. No.
1	13000-ARA-0005	Crank shaft COMP	1
2	13010-ADB-0000	Piston ring set	1
3	13101-ARA-0000	Piston	1
4	13111-ARA-0000	Piston pin	1
5	94601-15000	Piston pin clip	1

E-14 CARBURETOR




Ref. No	Part Number	Description	Reqd. No.
1	16100-Z7A-0001	Carburetor ASS'Y	1

F-01 Head Light




Ref. No	Part Number	Description	Reqd. No
1	33100-ATA-0200	Head light ASSY	1
2	33101-ATA-0200	Head light lens	1
3	33400-ATA-0100	FR. R winker ASSY	1
4	33450-ATA-0100	FR. L winker ASSY	1
5	34901-X06-0000	Head light bulb	1
6	93903-34380	Tapping screw 4X12	13

F-02 Speed Meter




Ref. No	Part Number	Description	Reqd. No
1	37200-X4A-0001	Speedometer ASSY	1
2	44830-APA-0002	Speedometer cable COMP	1
3	93903-34320	Tapping screw 5X16	3

F-03 Cable • Switch • Handle Lever




Ref. No	Part Number	Description	Reqd. No
1	17910-ARA-0000	Throt cable COMP	1
2	53100-ARB-0003	STRG. handle	1
3	53125-M9Q-0000	HNDL. set collar	1
4	53140-S1F-H001	RH. HNDL. grip	1
5	53166-S1F-H001	LH. HNDL. grip	1
6	53167-H09-9001	THROT. UND. housing	1
7	53168-H09-0001	Up thort housing	1
8	90106-M9Q-0000	Flange bolt 10X50	1
9	93500-05025-08	Pan screw 5*22	1
10	93903-34320	Tapping screw 4X16	2
11	90304-M9Q-0000	Flange nut 10MM	1

F-04 Front Brake Master Cylinder




Ref. No	Part Number	Description	Reqd. No
1	35342-M9Q-0000	FR. stop SW. ASSY	1
2	45100-APA-0002	Caliper ASSY	1
3	45126-APA-0000	FR. brake hose ASSY	1
4	45500-AAG-0000	FR. master cylinder	1
5	53175-T6V-0000	R. Steering handle lever	1
6	90145-M9Q-0000	Oil bolt M10x22	2
7	90545-M9Q-0000	Oil bolt washer	4
8	95801-06022-07	Flange bolt 8*30	2
9	45105-APA-0000	Pad A COMP	1
10	45106-APA-0000	Pad B COMP	1
11	4550A-APA-0003	FR. master cylinder ASSY	1

F-05 Handle Pipe • Handle Cover




Ref. No	Part Number	Description	Reqd. No
1	35150-M9F-A000	Lighting SW. UNIT	1
2	35160-M9Q-0002=	Start SW. UNIT	1
3	35170-A45-0003=	Dimmer and open SW. UNIT	1
4	35180-M9Q-0002	Horn SW. UNIT	1
5	35200-M9Q-0001=	Winker SW. UNIT	1
6	53205-X3A-0000-AD	FR. handle cover ASSY (gray)	1
6	53205-X3A-0000-KG	FR. handle cover ASSY (black)	1
6	53205-X3A-0000-RD	FR. handle cover ASSY (red)	1
6	53205-X3A-0000-SB	FR. handle cover ASSY (silver)	1
6	53205-X3A-0000-WA	FR. handle cover ASSY (white)	1
6	53205-X3A-0000-Y	FR. handle cover ASSY (yellow)	1
7	53206-APA-0000	RR. handle cover	1
8	53270-X3A-0000	Handle visor	1
9	88110-ANA-0000	R. back mirror ASSY	1
10	88120-ANA-0000	L. back mirror ASSY	1
11	93891-05018-07	Washer screw 5X18	1
12	93903-25320	Tapping screw 5X16	4
13	93903-24320	Tapping screw 4X12	4

F-06 Front Cover • Front Inner Box




Ref.	Part Number	Description	Reqd.
1	38300-T40-0101=	Winker relay	1
2	64303-APA-0001-AD/KG/RD/SB/WA/Y	Under spoiler	1
3	64301-X3A-0000-AD/KG/RD/SB/WA/Y	FR cover	1
4	64302-X3A-0000-AD/KG/RD/SB/WA/Y	Top cover	1
5	64318-ALA-0000	Frame number lid	1
6	77233-M9Q-0000	Inner box lock ASSY	1
7	81131-ARA-0002	Inner box	1
8	11204-ABA-0000	Spring hook pin	1
9	81141-APA-0000	Inner box lid	1
10	81142-APA-0000	RH. inner box lid plate	1
11	81142-APA-0000	LH. inner box lid plate	1
12	81146-APA-0000	Inner box seal	1
13	87123-H85-0000	S logo	1
14	90110-X3A-0000	Special screw 6X14	2
15	90115-G02-0000	Bolt 6X16	1
16	90308-X04-0000	Spring nut 5MM	8
17	93903-35320	Tapping screw 4X12	4
18	93903-35380	Tapping screw 5X16	6
19	93903-45380	Tapping screw 5X16	10

F-07 Floor Panel • Center Cover




Ref. No	Part Number	Description	Reqd. No
1	50611-APA-0001	Under cover	1
2	50612-APA-0000	Floor step lap A	4
3	64310-APA-0000	Floor panel	1
4	80153-APA-0000	Maint cover	1
5	90111-AAA-0000	Flange bolt 6mm	4
6	90302-V02-0001	Spring nut 4mm	4
7	90308-X04-0000	Spring nut 5mm	4
8	93903-35320	Tapping screw 5*16	5
9	93404-06016-00	Washer bolt 6*16	4

F-08 Body Cover




Ref. No	Part Number	Description	Reqd. No
1	81200-X3A-0000	RR carrier	1
2	83500-X3A-0000-AD/KG/RD/SB/WA/Y	RH. body cover	1
3	83520-APA-0001-AD/KG/RD/SB/WA/Y	RH. side cover	1
4	83600-X3A-0000-AD/KG/RD/SB/WA/Y	LH. body cover	1
5	83620-APA-0001-AD/KG/RD/SB/WA/Y	LH. side cover	1
6	96001-06016-07	SH. flange bolt 5X14	4
7	90308-X04-0000	Spring nut 5MM	2
8	90105-APA-0000	Special bolt 8X45	1
9	93903-35320	Tapping screw 5X16	10
10	90105-M92-0000	Special bolt 8MM	2
11	83501-X3A-0000	RH. Body garnish	1
12	83601-X3A-0000	LH. Body garnish	1
13	80152-X3A-0000	Center cover	1

F-09 Steering Stem • Front Cushion




Ref. No	Part Number	Description	Reqd. No
1	45156-A6A-0000	FR. brake hose clamp	1
2	45451-N02-0003	Wire grommet	1
3	50301-M9Q-0002	STRG. up race ball	1
4	50302-M9Q-0000	Ball race	1
5	50306-M9Q-0000=	STRG. stem lock nut	1
6	51400-APA-0001=	FR. RH. cushion ASSY	1
7	51500-APA-0001=	FR. LH. cushion ASSY	1
8	53200-APG-0000	Steering stem COMP	1
9	53211-M9Q-0000=	STRG. top cone race	1
10	53212-M9Q-0000	Race cone	1
11	61101-X3A-0000-AD/KG/RD/SB/WA/Y	FR. fender	1
12	61104-APA-0000	FR. fender rubber	3
13	61105-APA-0000	FR. brake hose clamp stay	1
14	61201-APA-0000	FR. fender collar	3
15	90115-G02-0000	Bolt 6X16	2
16	95801-08040-00	Flange bolt 8X40	4
17	96001-06020-08	Flange bolt SH. 6X20	3
18	50303-AAA-0000	Ball steel 5	1
19	50304-AAA-0000	Steel ball 8	1

F-10 Front Wheel




Ref. No	Part Number	Description	Reqd. No
1	42753-ABA-0000	Rim valve	1
2	44301-APG-0000	FR. wheel axle	1
3	44311-GW0-9100=	Collar FR. wheel side	1
4	44600-X3B-0000	FR. wheel ASSY	1
5	44601-X3A-0000	FR. cast wheel COMP	1
6	44620-APG-0000	FR. axle dist collar	1
7	42710-ARB-9000	FR. tire	1
8	44800-APA-0101	SPDMT. gear box ASSY	1
9	45121-ATE-0000	FR. brake disk	1
10	90105-KR3-000A	FR. disk bolt 8X24	3
11	90306-X11-A000	Self lock nut 12MM	1
12	90754-M9Q-0000	Dust seal 20X32X5	1
13	90912-M9Q-0000	Bearing 6201	2

F-11 Rear Wheel




Ref. No	Part Number	Description	Reqd. No
1	35342-M9Q-0000	FR. stop SW. COMP	1
2	42600-X3B-0000	RR. wheel ASSY	1
3	42601-X3A-0000	RR. cast wheel COMP	1
4	42710-ARB-9000	RR. tire	1
5	42753-ABA-0000	Rim vavle	1
6	43100-ARB-0000	RR. caliper ASSY	1
7	43105-ARB-0000	Pad COMP A	1
8	43106-ARB-0000	Pad COMP B	1
9	43126-APG-0001	RR. brake hose COMP	1
10	43500-ARB-0000	RR. M/C ASSY	1
11	4350A-APG-0002	RR. brake ASSY	1
12	45121-ATE-0000	RR. brake disk	1
13	53178-ARB-0000	L. STRG. handle lever	1
14	90145-M9Q-0000	Oil bolt 10*22	2
15	90545-M9Q-0000	Oil bolt washer	4
16	90131-ARB-0000	Flange bolt 8*35	2
17	90105-KR3-000A	RR. disk bolt 8*24	3
18	5210A-ARB-0002	RR. fork ASSY	1
19	52100-ARB-0101	RR. fork	1
20	11203-M9Q-3000	RR. CUSH. UN. rubber bush	1
21	95801-08035-07	Flange bolt 8*35	1
22	95801-08045-07	Flange bolt 8*45	2
23	95801-08064-07	Flange bolt 8X64	2

F-12 Seat • Rear Grip




Ref. No	Part Number	Description	Reqd. No
1	36600-A1A-0101	ENG. start control SW.	1
2	77200-X3A-0000	Double seat COMP	1
3	77201-AAA-0000	Seat hinge COMP	1
4	77230-APA-0006	Seat catch COMP	1
5	77240-APA-0002	Seat lock cable	1
6	81250-APA-0002	Luggage box	1
7	90105-HHA-0000	Seat hinge screw	1
8	90305-M9Q-9001	Clip nut 16MM	1
9	93404-06012-07	Washer bolt 6x12	4
10	94050-06000	Flange nut 6MM	2
11	95701-06012-08	Flange bolt 6*10	2
12	35870-HLA-0001	DC SOL. ASSY	1

F-13 Fuel Tank




Ref. No	Part Number	Description	Reqd. No
1	16910-M9Q-0001	Fuel strainer ASSY	1
2	16950-M9Q-0001	Fuel cock ASSY	1
3	17500-X3A-0002	Fuel tank COMP	1
4	17620-CT1C-A000	Fuel filler cap COMP	1
5	17682-APA-0000	Fuel tube (400MM)	1
6	17683-Z6A-0000	Fuel tube (170MM)	1
7	17684-APA-0001	Vacuum tube	1
8	37800-ARB-0003	Fuel unit	1
9	37801-M9Q-0001	Base packing	1
10	37802-M9Q-0000	Ret fuel unit	1
11	95002-02070	Tube clip B7	2
12	95002-02080-0A	Tube clip B8	4
13	95701-06012-08	Flange bolt 6X12	4

F-14 Battery • Tool Box




Ref. No	Part Number	Description	Reqd. No
1	31500-EG13-P000	Battery ASSY	1
2	32411-ARA-0100	Battery cable	1
3	89010-V1F-A001	Tool	1

F-15 Air Cleaner




Ref. No	Part Number	Description	Reqd. No
1	11211-ARA-0100	Breather tube	1
2	17200-ARA-0101	AIR cleaner ASSY.	1
3	17211-ADB-0000	AIR/C element COMP.	1
4	17230-ARA-0100	AIR/C case COMP.	1
5	17231-APA-0003	AIR/C cover COMP.	1
6	17253-ARA-0101	AIR/C connecting tube	1
7	17257-APA-0002	AIR/C duct A	1
8	17258-APA-0002	AIR/C duct B	1
9	17260-APA-0000	Air chamber	1
10	90652-M9Q-0000	AIR/C. CONN. tube band 46	1
11	93404-06030-07	Washer bolt 6*30	2
12	93903-25480	Tapping screw 5*20	9
13	95003-23019-60	V tube 8*12*190	1

F-16 Exhaust Muffler




Ref. No	Part Number	Description	Reqd. No
1	18000-ARH-0003	EXH. muffler ASSY	1
2	18292-A6A-0001	EXH. pipe gasket	1
3	90301-X3A-0000	Nut muffler joint M7	2
4	1865A-ARA-0003	A.I.C.V. unit	1
5	18317-KAA-0000	Muffler protector COMP	1
6	96001-06022-49	Flange bolt SH 6*22	3
7	18300-ARB-0201	Exhaust muffler COMP	1

F-17 Main Stand • Kick Starter Arm




Ref. No	Part Number	Description	Reqd. No
1	28300-F6C-0000	Kick starter arm ASSY	1
2	50500-X4A-0003	Main stand COMP	1
3	50503-F6B-0000	Main stand washer	2
4	50504-Z6A-0000	Main stand collar	2
5	50522-APA-0000	Main stand SPG.ASSY	1
6	50506-ABA-0000	Stand stop rubber A	2
7	5050A-X4A-0003	Main stand ASSY	1
8	50530-Z7E-0000	Side stand COMP	1
9	95014-72102-04	Side stand spring	1
10	50542-AAA-0000	Spring plate hook	1
11	90108-AAA-0000	Side stand pivot screw	1
12	94030-08080-0S	HEX. nut 8MM	1
13	95801-06022-07	Flange bolt 6X22	1
14	50512-ARA-0002	Flange bolt	1
15	90309-M9Q-0001-M2	Self-lock nut 8MM	1

F-18 Tail Light • RR. Cushion




Ref. No	Part Number	Description	Reqd. No
1	33700-ATA-0200	Tail light ASSY	1
2	33701-ATA-0100	Tail light lens	1
3	33740-APA-0000	License light ASSY	1
4	34906-M9Q-0001=	Tail light bulb	1
5	52400-ARB-0003	RR. cushion ASSY	2
6	80100-X3A-0001	RR. fender	1
7	80106-ARA-0001	RR. inn fender	1
8	93903-35320	Tapping screw 5*16	1
9	93903-35280	Tapping screw 5x12	4
10	95801-06012-07	Flange bolt 6x12	2
11	90115-G02-0000	Bolt 6*16	1
12	95801-08035-07	Flange bolt 8X35	2
13	95801-10035-08	Flange bolt 10X35	2

F-19 Wire Harness




Ref. No	Part Number	Description	Reqd. No
1	30410-T3A-A000	CDI. UNIT COMP	1
2	3051A-ARA-0100	IGN. COIL. ASSY	1
3	31600-CT3-A000	REG. REC. COMP	1
4	32100-ARB-0201	Wire harness	1
5	35010-Z6A-0100	Key set	1
6	35100-ALA-0100	Comb sw and lock ASSY	1
7	35114-ALA-0000	Cap	1
8	35111-AA3-A000	Key	2
9	35400-M92-0004	Resistor COMP	1
10	35850-35A-A000	MAG. SW. COMP	1
11	35859-M9Q-0001	Start MAG. SW. NUT	2
12	38110-ABA-0001	Horn COMP	1
13	38300-T40-0101=	Ap winker relay ASSY	1
14	77240-APA-0002	Seat lock lable	1
15	90112-M9Q-0000=	Flange bolt 5X22	1
16	93891-05010-08	Screw washer 5X10	1
17	95701-06012-08	Flange bolt 6X16	2
18	95801-06018-00	Flange bolt 6X18	2
19	95801-08012-08	Flange bolt 8X12	1

F-20 Frame Body • Engine Hanger



Ref. No	Part Number	Description	Reqd. No
1	11345-ARA-0000	L. cover duct A	1
2	11346-M9Q-0000	L. cover duct band	1
3	11346-M9Q-0000	L. cover duct B	1
4	11347-APA-0000	L. cover duct C	1
5	1134B-ARA-0001	L. cover duct ASSY	1
6	17242-M9Q-0000	AIR/C duct band	1
7	32160-VS1-0000	Wire band 5X180	2
8	44301-APG-0000	Flange bolt	1
9	50100-X3A-0103	Frame body COMP	1
10	50350-ARA-0100	EHG. hanger ASSY	1
11	50351-ARA-0100	EHG. stopper COMP	1
12	50352-ADB-0000	Link stopper rubber	1
13	50353-M9Q-0000	Swing lock bush	2
14	50710-APA-0002	RH. pillion step ASSY	1
15	50715-APA-0001	RH. pillion step	1
16	50718-APA-0001	LH. pillion step	1
17	50720-APA-0002	LH. pillion step ASSY	1
18	81208-ARA-0003	DC solendid cover	1
19	90106-M9Q-9001	Flange bolt 10X55	2
20	90121-M9Q-0001	Distance collar	1

F-20-2 Frame Body • Engine Hanger



Ref. No	Part Number	Description	Reqd. No
21	90304-M9Q-0000	Flange u nut 10MM	1
22	95701-06012-08	SH. flange bolt 6X12	3

F-22

Ref. No	Part Number	Description	Reqd. No

MOTOMANIA